



TRUST ON/OFF PISTORASIAVASTAANOTIN PÅ/AV UTTAGSMOTTAGARE - ON/OFF SOCKET RECEIVER

05/2026



Vastaanotin / Mottagaren / Receiver




Kytin / Brytaren / Switch



1 -> 2 kanavaa / kanaler / channel




Cr2032 pariston asennus / montering av batteri / installing the battery




Kytikimen seinäasennus / Vägghmontering av strömbrytare / Switch Wall Mounting

Paritus / Parkoppling / Linking



1
Työnnä vastaanotin pistorasiaan.
Sätt mottagaren i vägguttaget.
Plug the receiver into the socket.




2
Paina ON-kytintä lyhyesti.
Tryck kort på ON-knappen.
Briefly press the ON button.




3
Linkitys on valmis, kun vastaanotin naksahtaa 4 kertaa.
Parkopplingen är färdig när mottagaren klickar 4 gånger.
Pairing is complete when the receiver clicks 4 times.

Parituksen poisto / Avparkoppling / Unlinking



1
Irrota vastaanotin pistorasiasta ja työnnä takaisin.
Dra ut mottagaren ur vägguttaget och sätt tillbaka den.
Unplug the receiver and plug it back in.



2
Paina 6 sekunnin sisällä OFF-kytintä lyhyesti.
Tryck kort på OFF-knappen inom 6 sekunder.
Briefly press the OFF button within 6 seconds.



3
Linkitys on poistettu, kun vastaanotin naksahtaa 4 kertaa.
Parkopplingen har tagits bort när mottagaren klickar 4 gånger.
The pairing is unlinked when the receiver clicks 4 times.



Model	91422140, 91422141
	91422130 + 91422131, 91422132

Maximum load	2300 Watt
Power	220-240VAC 50Hz
RF	433,92 MHz

LEDCUT 2026 • VALONOHJAUS

LEDCUT

HtF Group Oy
Yrittäjätie 6
60100 Seinäjoki

info@htfgroup.fi

